



***R&B Wire Products, Inc.***

## **ASSEMBLY INSTRUCTIONS**

STANDARD PRIVACY SCREEN PSS-3 OR PSS-3C



- 1) Install bottom base with casters to each tube as shown above using  $\frac{1}{4}$ " x  $1\frac{3}{4}$ " bolt and tighten lock nut.
- 2) To replace vinyl panels, grasp curtain rod at end away from spring retainer clip and slide rod towards clip. This will release rod from frame.
- 3) Periodically check all fasteners for tightness. To clean vinyl panels use only a mild soap and water.

### **WARNING**

- To avoid injury, never stand or ride on screen legs.
- Keep casters free of thread, lint, hair and other debris.
- Be sure casters roll freely and turn easily at all times.
- Do not use for personal support.
- Be careful when rolling over uneven surfaces.
- Do not hang anything on screen frames.



2902 W. Garry, Santa Ana, California 92704  
714/549-3355 • 800/634-0555 Toll Free • Fax 714/549-0625  
E-mail: [sales@rbwire.com](mailto:sales@rbwire.com) [www.rbwire.com](http://www.rbwire.com)



"YOUR RELIABLE PARTNER  
FOR OVER 57 YEARS"